The Hong Kong University of Science and Technology Cisco Unified IP Phone 6945 User Quick Reference



Service Features	Access
Internal Call	Dial 4 digits extension no.
External Call	Dial 9 + tel. no.
Speakerphone (Handsfree Speaker)	Press (Green Light is on)
• On	
• Off	Press 🕜 again
Audio Mute	During a call, press (Red Light is on)
• On	During a can, press (Red Light is on)
• Off	Press 🕜 again
Redial (redial last dialed number)	Press { Redial }
Call Hold	Press $(\text{the } 1^{\text{st}} \text{ line button flashes})$
• put a line on hold	green)
• reconnect the call	Press { Resume } or
Call Transfer	(1) + Ext. No. / 9 + Tel No. + (1) / { Transfer }
• transfer	
• reconnect (<i>if the line is no answer / busy</i>)	Press { Cancel } + { Resume }
Conference (8 Parties Audio/Video Calls)set up	
• reconnect (if the line is no answer / busy)	Press { Cancel } + { Resume }
• remove a party from conference	Press Show Details + + select a party + { Remove }
Call Pickup	
• group pickup	Lift the handset and press { PickUp }
Call Park (Hold a call and retrieve it at another	
phone)	
• park a call	During a call, press { Park } (Screen shows a 4-digit Park No.)
reconnect a parked call	Enter the Park No. at another phone
Call Forward	Press { Forward All } + Ext. No.
• set up (all calls)	(Screen shows ${\leftarrow}$ & "Forwarded to XXXX")
cancel	Press { Forward Off }

Service Features		Access					
Immediate Divert (send	l an incoming call to	Press { Divert }					
voicemail system)							
Access Voicemail System (Note: The new voiceman instead of 8000)	m il system number is <u>5000</u>	When having voicemail, Message Waiting Indicator is on (Red).					
• internal access		Press (C) or dial 5000, enter pin no.#					
external access		Dial 2358 5000, enter 4-digit extension no. & pin no.#					
Call Log (total stores up	o to 150 records)						
• dial from call log		Settings / Applications					
		+ (1. Call History) + select a call log record + Press { All Call } or { Missed Call }					
		Received - , Placed - , Missed - , + { Edit Dial } to edit the displayed number if necessary + { Dial } / lift the handset to start calling					
Personal Directory (Per	rsonal Address Book)						
• sign in for Personal	Address Book (PAB)	 + (1. Personal Directory) + enter User ID & Phone PIN + { Submit } Use the Navigation bar and button to scroll and select 					
• search for an entry		Log into PAB + enter Search Criteria + { Find }					
dial from entry		Search for an entry + { Dial } + select a Phone No. + { OK } + { OK }					
Arrow	Up	Press up arrow key to review call history. Select a number to edit and dial					
Keys 関	Down	Press down arrow key to review the speed dial buttons, highlight the stored speed dial, then lift up handset to dial					
Phone Settings Web Po	ortal (Cisco Unified CM	Launch a web browser, & go to <u>https://cm.uc.ust.hk/ccmuser</u>					
End User Options) (On		Login using Portal Password					
Contrast		Press (+ (2. Preferences)					
		+ (2. Contrast) + to adjust + { Save } to confirm					
Ring Tone		Press (2) + (2. Preferences)					
		+ (1. Ring Tone) + to change +					
		select Ring Tone + { Play } to listen / { Set } + { Apply } to use					
Volume							
• adjust the handset, h	eadset and speaker volume	When handset, headset or speaker is in use (off hook), press:					
• adjust the ringer volu	ume	When handset, headset and speaker is not in use (on hook), press:					

	Buttons / Keys										
	Ø	8	@	•		Ø	٨	O		X	
Handsfree Speaker	Audio Mute	Hold	Transfer	Conference	Navigation (Up, Select, Down)	Voicemail	Settings / Application	Contacts	Volume Control	Forwarded icon	{ } Softkey